



**SHERWIN
WILLIAMS®**

101.010GA

EMERALD®

**Urethane Trim Enamel
Interior-Exterior Waterbased
Gloss**

K39-1751/750 SERIES (US)

K39Q-8851/8750 SERIES (CANADA)

As of 01/14/2019, Complies with:

OTC	Yes	LEED® 09 NC CI	Yes
OTC Phase II	Yes	LEED® 09 CS	Yes
SCAQMD	Yes	LEED® 09 H	Yes
CARB	Yes	LEED® v4 Emissions	No
CARB SCM 2007	Yes	LEED® v4 VOC	Yes
Canada	Yes	MPI	

CHARACTERISTICS

Emerald Urethane Trim Enamel is a waterbased “Best-In-Class” quality interior/exterior enamel formulated with a urethane modified alkyd resin system for premium quality and performance. It delivers the look, feel and durability of an oil based enamel with the convenience of a waterbased formula. Excellent flow and leveling, gloss and color retention when applied to interior/exterior surfaces such as properly prepared drywall, wood, masonry and metal.

Color: Many colors
To optimize hide and color development, always use the recommended P-Shade primer

Coverage: 350 - 400 sq ft/gal
(8.6-9.8 m²/L)

@ 4 mils wet; 1.3 mils dry

Drying Time, @ 77°F(25 °C), 50% RH:

Touch: 2 hours

Recoat: 4 hours

Drying and recoat times are temperature, humidity, and film thickness dependent

Finish: Gloss 65+ units @ 60°

Tinting with CCE only:

Base	oz/gal	Strength
------	--------	----------

High Hide White	0-6	Shercolor
-----------------	-----	-----------

Deep Base	4-12	Shercolor
-----------	------	-----------

Ultradeep Base	10-14	Shercolor
----------------	-------	-----------

To optimize hide and color development, always use the recommended P-shade primer

High Hide White K39W01751

(may vary by color and base)

VOC (less exempt solvents):

<50 g/L; 0.42 lb/gal

As per 40 CFR 59.406

Volume Solids: 32 ± 2%

Weight Solids: 49 ± 2%

Weight per Gallon: 10.68 lb (4.84 kg)

Flash Point: N/A

Vehicle Type: Urethane modified alkyd

Shelf Life: 36 months unopened

APPLICATION

Apply at temperatures above 50°F(10°C)
No reduction needed.

Brush

Use a nylon/polyester brush.

Roller

Use a high quality 1/4"-1/2" woven roller cover.

Spray-Airless

Pressure..... 2000 psi

Tip013"-.017"

SPECIFICATIONS

Interior:

Drywall

1ct. ProMar 200 Zero VOC Primer

2cts. Emerald Urethane Trim Enamel

Plaster

1ct. Premium Wall & Wood Primer

2cts. Emerald Urethane Trim Enamel

Wood

1ct. Premium Wall & Wood Primer

2cts. Emerald Urethane Trim Enamel

Interior & Exterior:

Aluminum, Galvanized & Steel

1 ct. All Surface Enamel Latex Primer

2cts. Emerald Urethane Trim Enamel

Block

1ct. Loxon Block Surfacers

2cts. Emerald Urethane Trim Enamel

Masonry, Cement, Stucco

1ct. Loxon Concrete & Masonry Primer

2cts. Emerald Urethane Trim Enamel

Exterior:

Wood, Composition Board

1ct. Exterior Oil-Based Wood Primer

Or Exterior Latex Wood Primer

2cts. Emerald Urethane Trim Enamel

Other primers may be appropriate.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (**NIOSH** approved) and proper containment and cleanup. For more information, call the National Lead Information Center at **1-800-424-LEAD** (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Aluminum and Galvanized Steel

Wash to remove any oil, grease, or other surface contamination. All corrosion must be removed with sandpaper, wire brush, or other abrading method.

Caulking

Gaps between windows, doors, trim, walls, ceilings, crown moldings and other trim can be filled with the appropriate caulk after priming the surface.

Concrete Block All new surfaces must be cured according to recommendations—usually about 30 days. Rough surfaces can be filled with Loxon Block Surfacers to provide a smooth surface. The filler must be thoroughly dry before topcoating.

Drywall

Fill cracks and holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

Masonry, Concrete, Cement

All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer.

SURFACE PREPARATION

Mildew

Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.

Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.

Steel

Rust and mill scale must be removed using sandpaper, wire brush, or other abrading method. Bare steel must be primed the same day as cleaned.

Stucco

Remove any loose stucco, efflorescence, or laitance. Allow new stucco to cure at least 30 days before painting. If painting cannot wait 30 days, allow the surface to dry 7 days and prime with Loxon Concrete & Masonry Primer. Repair cracks, voids, and other holes with an elastomeric patch or sealant.

Wood, Plywood, Composition Board

Clean the surface thoroughly then sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. All patched areas must be primed. Knots and some woods, such as redwood and cedar, contain a high amount of tannin, a colored wood extract. If applied to these bare woods, it may show some staining.

Exterior: If staining persists, spot prime severe areas with 1 coat of Exterior Oil-Based Wood Primer prior to using.

Interior: If staining persists, spot prime severe areas with 1 coat of Multi-Purpose Oil-Based Primer

CAUTIONS

Protect from freezing.

Non-photochemically reactive.

For exterior use on doors, trim, and other small areas of wood or metal. Do not use on the main body of exterior structures.

Before using, carefully read **CAUTIONS** on label.

Use only with adequate ventilation. To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying. If you experience eye watering, headaches, or dizziness, increase fresh air, or wear respiratory protection (**NIOSH** approved) or leave the area. Avoid contact with eyes and skin. Wash hands after using. Keep container closed when not in use. Do not transfer contents to other containers for storage. **FIRST AID:** In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately. **WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. **DO NOT TAKE INTERNALLY. KEEP OUT OF THE REACH OF CHILDREN.**

HOTW 01/14/2019 K39W01751 03 36

DANGER: Rags, steel wool, other waste soaked with this product, and sanding residue may spontaneously catch fire if improperly discarded. Immediately place rags, steel wool, other waste soaked with this product, and sanding residue in a sealed, water-filled, metal container. Dispose of in accordance with local fire regulations.

HOTW 01/14/2019 K39W00753 07 38
FRC, SP, KOR

CLEANUP INFORMATION

Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.